



INA FEAD Belt – What does the description stand for?



Abbreviations for belt types:

PK

PK = Standard:

- For conventional belt drives
- Including for belt drives with start/stop function using a starter (pinion starter)

XPK

X = EXTRA:

- For complex belt drives
- Special structure: for example, aramid cord, special rib material
- Suitable for belt drives with start/stop function (pinion starter)
- Enables very small deflections and high bending cycles

APK

A = BAS

(Belt Alternator Starter):

- For belt drives with a starter alternator
- Silent and vibration-free restarts throughout the entire service life

DPK

D = Double:

- For compact belt drives
- Belt with double-sided ribbed profile
- Auxiliary units are driven on both sides of the belt

EPK

E = ELAST:

- For belt drives without a tensioner
- Specially designed tension members which maintain maximum belt tension
- Requires a special installation tool to prevent overstretching or damage to the belt during fitment